


Quickstart Guide for Zenput Gateways and Sensors

⚠ Please read the instructions completely before getting started. Failure to do so could delay sensor readings by hours.

INSTALLATION OVERVIEW

1. Unbox the devices and log into Zenput from the location where you will install them.
2. Register the gateway in Zenput and connect it to power and to the internet.
3. Register each sensor in Zenput before powering it on and placing it.



STEP BY STEP INSTALLATION

Step 1: Unbox devices and open the Zenput app

- Remove devices, antennas, and cables from the box.
- Connect antennas to the gateway.
- Open the Zenput mobile app and navigate to your store location.
- Navigate to the Sensors tab for your location.

Step 2: Register the gateway in Zenput

- Select "Set Up Gateway" in the Sensors tab and complete the registration process.
- Plug the gateway into an electrical outlet.
- Connect the gateway to the internet:
 - Plug-in the ethernet cable that came in the box into the gateway and into the router.
 - Cellular gateways will automatically connect to the network when powered on.



Step 3: Register each sensor in Zenput and then power on and place the sensor

Note: Do not remove the battery tab until it has been registered in Zenput

- Select "Add Sensor" from the Sensors tab and complete the registration process.
- Attach any external probes to the sensors.
- Remove the battery cover with small Phillips screw driver and pull the battery tab.
- Place the sensor in the desired location.

Gateways and sensors will appear in the Sensors tab for the location where they were registered. Sensors will show "initializing" while they complete their wake-up process which can take 10 minutes to an hour.

